

Code List

TV Codes

Abex.....	185	Marantz.....	.004, 009, 062
Acme.....	.039, 050	Megatron.....	.004, 009, 059
ADA.....	007, 008	MEI.....	.014
ADC.....	003	Memorex.....	.000, 001, 004, 009, 049, 051, 135
Admiral.....	001, 173	MGA.....	.004, 005, 009, 022, 051, 180
Adventura.....	174	Midland.....	.015, 054, 055, 107, 121, 172
Aiko.....	.058	Minutz.....	.052
Aiwa.....	195, 196	Mitsubishi.....	.004, 005, 009, 022, 051, 081, 089, 132, 180
Akai.....	002	Montgomery Ward.....	.000, 001
Alleron.....	.051	Motorola.....	.003, 173
Amark.....	.020	MTC.....	.004, 005, 009, 014, 105, 109
Amtron.....	.053	Multitech.....	.053
Amstrad.....	.189	Multivision.....	.084
Anam National.....	.003, 025, 042, 053, 193	NAD.....	.004, 009, 109, 185
AOC.....	.004, 005, 007, 009, 014, 132, 156, 175	NEC.....	.003, 004, 005, 009, 010, 085, 089, 095
Apex.....	214	Nikei.....	.042
Archer.....	.020	Nikko.....	.004, 009, 058
Audiovox.....	.053	NTC.....	.058
Bang & Olufsen.....	.190	Onking.....	.042
Belcor.....	.004	Onwa.....	.042, 053
Bell & Howell.....	.000, 001, 049	Optimus.....	.170, 185
Bradford.....	.053	Optonica.....	.095, 173
Broksonic.....	136, 147	Orion.....	.035, 121, 135
Brokwood.....	.004	Panasonic.....	.003, 054, 055, 062, 070, 148, 170, 171
Candle.....	.004, 008, 009, 174	Philco.....	.003, 004, 005, 008, 009, 062, 068, 069, 074, 075, 077
Capehart.....	175	Philips.....	.003, 004, 006, 008, 062, 068, 069, 074, 075, 086, 087, 089, 163, 183, 184, 205, 206, 207, 208, 212, 213
Celebrity.....	.002	Philips/Magnavox.....	.183, 184, 204, 208, 213
Centurion.....	.009	Pilot.....	.004
Cetronic.....	.042	Pioneer.....	.004, 009, 090, 179, 185
Changhong.....	.214	Portland.....	.004, 005, 009, 058
Citizen.....	.001, 004, 008, 009, 042, 053, 058, 105, 109, 177	Precision.....	.166
Clairtone.....	.014	Price Club.....	.105
Classic.....	.042, 214	Prism.....	.055
Colortyme.....	.004, 009, 010	PROSCAN.....	.000, 015, 031, 107
Concerto.....	.004, 009	Proton.....	.004, 009, 093, 175, 186, 192
Concierge.....	.121	Pulsar.....	.004, 121
Contec/Cony.....	.012, 013, 014, 042, 053	Quasar.....	.003, 054, 055, 062, 070, 148, 170, 171
Craig.....	.042, 053	RadioShack.....	.000, 004, 009, 031, 041, 042, 048, 049, 053, 095, 155, 170, 172, 194
Crown.....	.042, 053	RCA.....	.000, 003, 004, 005, 007, 009, 011, 015, 048, 082, 092, 094, 096, 098, 101, 102, 103, 107, 113, 125, 129, 167, 179, 187, 188, 191, 194
Curtis-Mathes.....	.000, 001, 004, 009, 015, 031, 049, 073, 105, 109, 130	Realistic.....	.000, 004, 009, 031, 041, 042, 048, 049, 053, 095, 155, 170, 172
CXC.....	.042, 053	Rhapsody.....	.014
Daewoo.....	.004, 005, 009, 017, 018, 019, 042, 058, 082, 085, 097, 100, 126, 127, 130, 138	Runco.....	.121
Daytron.....	.004, 009	Sampo.....	.004, 009, 046, 172, 175
Dimensia.....	.000, 031	Samsung.....	.004, 005, 009, 015, 104, 105, 106, 109, 172
Dumont.....	.004, 121	Samsux.....	.009
Dynasty.....	.042	Sansui.....	.135, 136
Elektra.....	.001	Sanyo.....	.004, 013, 049, 108, 110, 180, 209
Electroband.....	.002, 014	Scotch.....	.004, 009
Electrohome.....	.003, 004, 009, 022	Scott.....	.004, 009, 024, 035, 042, 051, 053
Emerson.....	.004, 009, 014, 023, 024, 025, 026, 027, 030, 032, 033, 034, 035, 036, 037, 038, 039, 040, 041, 042, 043, 045, 049, 051, 053, 116, 135, 147, 155, 177, 179, 189, 198	Sears.....	.000, 004, 009, 013, 015, 031, 049, 051, 105, 107, 109, 110, 180, 189
Envision.....	.004, 009	Sharp.....	.004, 009, 079, 095, 111, 112, 114, 122, 123, 124, 173
Fisher.....	.013, 049, 180, 209	Shogun.....	.004
Fujitsu.....	.051, 197	Signature.....	.000, 001, 023
Funai.....	.042, 051, 053, 155, 189, 198	Simpson.....	.008
Futurtec.....	.042, 053	Sonic.....	.014
GE.....	.000, 003, 004, 009, 015, 022, 031, 044, 052, 054, 055, 087, 092, 103, 107, 125, 164	Sony.....	.002, 006, 071, 128
Gibraltar.....	.004, 121	Soundesign.....	.004, 008, 009, 042, 051, 053
Goldstar.....	.004, 005, 009, 056, 057, 155, 156, 172	Spectravision.....	.203
Grundy.....	.051, 053	Squareview.....	.189
Haier.....	.216, 217	SSS.....	.004, 042, 053
Hallmark.....	.004, 009	Starlite.....	.053
Harvard.....	.053	Supre-Macy.....	.174
Hitachi.....	.001, 004, 009, 013, 059, 060, 061, 088, 091, 137, 139, 141, 142, 143, 144, 145, 146, 179, 210	Supreme.....	.002
IMA.....	.053	Sylvania.....	.004, 008, 009, 062, 068, 069, 074, 075, 077, 155, 161, 163, 189, 198
Infinity.....	.062	Symphonic.....	.033, 053, 155, 189, 198
Inteq.....	.121	Tandy.....	.173
Janeil.....	.174	Tatung.....	.003
JBL.....	.062	Technics.....	.054, 055
JCB.....	.002	Techwood.....	.004, 009, 054, 055
JC Penney.....	.000, 004, 005, 008, 009, 015, 022, 030, 031, 052, 054, 055, 087, 105, 107, 109, 172	Teknika.....	.000, 001, 004, 005, 008, 009, 013, 042, 051, 053, 058, 105, 109, 170, 174
Jensen.....	.004, 009	Telecaption.....	.117
JVC.....	.013, 054, 055, 060, 065, 067, 089	Telerent.....	.000, 001
Kawasho.....	.002, 004, 009	Tera.....	.004, 186
Kaypani.....	.175	TMK.....	.004, 009
KEC.....	.042	Toshiba.....	.013, 049, 089, 105, 109, 117, 118, 120, 159, 178
Kenwood.....	.004, 009	Universal.....	.052, 087
Kloss Novabeam.....	.068, 069, 174	Victor.....	.060
Konka.....	.016, 047, 066, 157, 158, 176	Vidtech.....	.004, 005, 009
KTV.....	.014, 021, 042, 053, 070, 116, 177	Viking.....	.174
Lodgenet.....	.000, 001	Wards.....	.000, 001, 004, 005, 008, 009, 024, 031, 033, 051, 052, 062, 068, 069, 074, 075, 087, 095, 119
Loewe.....	.062, 211	White Westinghouse.....	.097, 100, 130, 155
Logik.....	.000, 001	Yamaha.....	.004, 005, 009
Luxman.....	.004, 009	Zenith.....	.000, 001, 004, 023, 038, 058, 059, 064, 073, 121, 135, 136, 153
LXI.....	.000, 004, 009, 015, 031, 049, 062, 107, 109		
Magnavox.....	.004, 008, 009, 062, 068, 069, 074, 075, 077, 089, 163, 165		
Majestic.....	.000, 001		

VCR Codes

Admiral.....	.001	Aiwa.....	.002, 020, 026, 044
Adventura.....	.026	Akai.....	.003, 004, 005, 006, 008, 029, 111, 112
Aiko.....	.027	Allegro.....	.018, 022, 104

VCR (continued)

American High	021, 060
Asha	134
Audio Dynamics	009, 123
Audiovox	014
Bell & Howell	043
Beaumarck	134
Broksonic	012, 025, 031, 064, 085
Calix	014
Candle	009, 014, 015, 016, 017, 019, 134
Canon	021, 060, 114, 115
Capehart	104
Carver	062
CCE	027, 061
Citizen	009, 014, 015, 016, 017, 019, 027, 134
Colortyme	009
Colt	061
Craig	014, 023, 061, 134
Curtis-Mathes	000, 002, 009, 016, 021, 024, 060, 109, 115, 133, 134
Cybermax	134
Daewoo	015, 017, 019, 025, 026, 027, 028, 054, 109
DBX	009, 123
Dimensia	000
Dynatech	002, 026
Electrohome	014, 029
Electroponic	014
Emerson	002, 006, 008, 012, 014, 015, 021, 024, 025, 026, 029, 030, 031, 032, 034, 036, 037, 038, 040, 041, 043, 044, 045, 047, 060, 065, 105, 116, 134
Fisher	009, 023, 042, 043, 048, 049, 050, 062, 079
Fuji	004, 021, 060
Funai	002, 008, 026
Garrard	026
GE	000, 021, 053, 060, 115, 117, 120, 134
Goldstar	009, 014, 121
Gradiente	026
Go-Video	134, 143
Harley Davidson	026
Harman Kardon	009, 068
Harwood	061
Headquarter	043
Hitachi	002, 055, 057, 107, 111, 120, 122, 144, 145
Hi-Q	023
Instant Replay	008, 021, 060
Inted	014
JCL	021, 060
JC Penney	009, 014, 043, 055, 060, 107, 111, 115, 118, 123, 134
Jensen	055, 111
JVC	009, 022, 043, 111, 123, 151, 152
Kenwood	009, 016, 043, 111, 123
KLH	061, 131
Kodak	014, 021, 060
Lloyd	002, 026
Logik	061
LXI	014
Magnavox	021, 060, 062, 104, 106, 115, 124
Magnin	134
Marantz	009, 016, 021, 043, 060, 062, 064, 114, 123
Marta	014
Matsushita	021, 060
MEI	021, 060
Memorex	001, 002, 014, 021, 023, 026, 043, 060, 104, 112, 134
MGA	029, 065
MGN Technology	134
Midland	053
Minolta	055, 107
Mitsubishi	029, 051, 052, 055, 065, 066, 068, 069, 070, 071, 073, 074, 123
Montgomery Ward	001, 075
Motorola	001, 021, 060

MTC	002, 026, 134
Multitech	002, 026, 053, 061, 134
Nec	009, 016, 024, 043, 064, 076, 077, 078, 111, 123
Nikko	014
Noblex	134
Olympus	021, 060
Optimus	001, 014, 134, 136, 137, 138, 149
Optonica	075, 134
Orion	031
Panasonic	021, 060, 115, 125, 138, 148, 149
Pentax	016, 055, 107, 120
Pentax Research	009
Philco	021, 060, 062, 115
Philips	021, 060, 062, 063, 075, 103, 106, 108, 124, 146, 153
Philips/Magnavox	108, 103
Pilot	014
Pioneer	055, 080, 081, 123
Portland	016, 017, 019
PROSCAN	000
Protec	061
Pulsar	104
Quarter	043
Quartz	043
Quasar	021, 060, 115, 125, 149
RCA	000, 003, 021, 055, 060, 082, 083, 084, 086, 087, 088, 089, 090, 091, 107, 110, 115, 117, 120, 125, 134, 137
RadioShack	000, 001, 002, 014, 021, 023, 026, 029, 043, 049, 050, 060, 075, 112, 115, 117, 134, 136, 137, 138
Radix	014
Randex	014
Realistic	000, 001, 002, 014, 021, 023, 026, 029, 043, 049, 050, 060, 075, 112, 115, 134, 136, 137, 138
Replay	148
Ricoh	128
Runco	104
Samsung	005, 015, 053, 055, 112, 129, 134
Sanky	001, 104
Sansui	111, 123
Sanyo	023, 042, 043, 079, 134
Scott	012, 015, 025, 032, 038, 065, 093, 116
Sears	014, 021, 023, 043, 048, 049, 050, 055, 060, 062, 107, 118
Sharp	001, 002, 017, 029, 075, 135, 136, 142
Shintom	004, 055, 061, 128, 132
Shogun	134
Signature	002
Singer	021, 060, 061
Sony	004, 099, 128, 139, 140, 141, 147, 154, 155
STS	021, 055, 060, 107
Sylvania	002, 008, 026, 060, 062, 065, 115, 124, 231
Symphonic	002, 008, 011, 026
Tandy	002, 043
Tashiko	014
Tatung	111
Teac	002, 026, 111
Technics	021, 060
Teknika	002, 014, 021, 026, 060, 100
Tivo	146, 147
Toshiba	015, 049, 055, 062, 065, 093, 116
Totevision	014, 134
TMK	024, 047, 134
Unitech	134
Vector Research	009, 015, 016, 123
Victor	123
Video Concepts	009, 015, 016, 029, 123
Videosonic	134
Wards	001, 002, 014, 015, 021, 023, 026, 029, 055, 060, 061, 075, 101, 107, 116, 134
White Westinghouse	002, 008
XR-1000	021, 026, 060, 061
Yamaha	009, 043, 111, 123
Zenith	001, 004, 007, 010, 014, 018, 022, 056, 058, 059, 085, 104, 119, 123, 128, 133, 145

DVD Codes

Aiwa	189
Akai	170
Ames	206
Apex	165, 166, 167, 199, 205, 220, 232, 234
A-Trend	168
Classic	206
Cyberhome	168
Daewoo	215, 216, 219
Denon	175, 196
Digitrex	220
Elta	209, 210
Emerson	171, 231, 233
Fisher	191
Funai	231, 233
GE	184, 205
Goldstar	171
Go-Video	182, 201
Gradiente	190
Harman Kardon	202
Hitachi	179, 194
Hiteker	220
Integra	197
JVC	181, 193
Kenwood	175, 204
KLH	205
Konka	185, 186, 187, 188
Koss	190
Lasonic	229
LG	171
Magnavox	173, 183
Marantz	171, 173, 183
Microsoft	178
Mintek	205

Mitsubishi	177
Mustek	206
NAD	171, 208
Nakamichi	207
Onkyo	197
Optimus	179
Oritron	190
Panasonic	175
Philips	173, 183, 198
Pioneer	179
Proline	190
PROSCAN	184
RadioShack	218, 224, 228
Reoc	226
RCA	178, 184, 205, 218, 224, 228
Samsung	182, 230
Sampo	192
Sanyo	191
SEG	203
Sharp	061, 107, 101, 107, 116, 134
Sherwood	200
Shinco	205
Sony	174
Sylvania	231, 233
Symphonic	231, 233
Teac	179
Technics	175
Tevion	221, 223, 225, 226, 227
Theta Digital	179
Toshiba	173, 211, 222
Wharfedale	217
Yamaha	175, 195
Yamakawa	213
Zenith	171, 180, 212

PVR/DVR Codes

Panasonic	148	Sonic Blue	148
Philips	146	Sony	147
RCA	184	TVo	146, 147
Replay TV	148		

VCR/DVD Combo Codes

Go-Video	230	Samsung	230
JVC	151	Sanyo	042, 191
Philips	183		

TV/VCR, TV/DVD Combo Codes

	TV	VCR/DVD		TV	VCR/DVD
Admiral	115	001	Magnavox	062	062
.....	124	001	115	001
Aiwa	155	002	Memorex	209	043
.....	155	008	Panasonic	148	138
Broksonic	136	085	Philips	062	062
Candle	153	014	212	063
Curtis-Mathes	073	133	Philips/Magnavox	148	103
Daewoo	039	027	Quasar	102	138
.....	097	027	RCA	194	117
.....	138	054	RadioShack	102	117
Emerson	039	027	194	117
.....	155	002	Samsung	073	129
.....	155	008	073	133
.....	198	231	Sansui	136	085
Fisher	209	043	Sanyo	209	043
Funai	155	002	Sharp	124	001
.....	155	008	Sony	002	155
.....	198	231	128	155
GE	102	117	Sylvania	155	002
.....	194	117	155	008
Goldstar	121	113	198	231
.....	153	014	Symphonic	155	002
.....	155	002	155	008
.....	155	008	198	231
Hitachi	155	002	White Westinghouse	155	002
Infinity	062	062	155	008
Konka	157	187	Zenith	036	041
.....	158	188	073	133
LG	121	113	097	027
.....	153	014	121	104
.....	155	002	121	113
LXI	155	002	136	085
.....	155	002	153	014

Satellite Receiver Codes

Amplica	115	DSS Panasonic	126, 166
Bell ExpressVu	168, 187, 194	Primestar	167, 180
Channel Master	117, 118, 119	Philips	116, 152, 179
Chapparral	100, 101	Philips/Magnavox	116, 152, 179
Cheyenne	101	Pioneer	124
Drake	102, 114, 127	PROSCAN	162, 176
Dish Network	128, 129, 130, 168, 187, 188, 194, 195	DSS RCA	176, 189, 192, 193, 198
DX Antenna	108, 122	Realistic	107, 143
Echosphere	168	Samsung	134, 153
Echostar	128, 129, 130, 168, 187, 194	Sharp	144
Fujitsu	131, 132	Sierra I, II, III	101
GE	162, 176	DSS Sony	125, 163
Gemini	135	StarChoice	167, 180, 185
General Instruments	104, 105, 106, 133, 180, 182, 183, 184, 185	Star Sight	173
DSS Hitachi	172, 181	Star Trak	148
DSS Hughes Satellite	169, 170, 172, 173, 178	STS	108, 110, 111
Jerrold	137	Super Guide	149
JVC	188	Thomson	154
Kenwood	138	Toshiba	112
Luxor	139	Toshiba DSS	164, 165, 171
DSS Magnavox	116, 152, 179	Uniden	113, 151
Macom State	140	DSS Uniden	173
Norstat	141	Video Cipher II	114
Pace	154, 155, 186	Zenith	102, 103, 114, 127, 135, 155, 174, 175, 186

HDTV/SAT Codes

Hughes	169, 170, 172, 178	Samsung	134, 153
Panasonic	126	Sharp	144
Philips	156	Sony	163
RCA	190, 198	Zenith	135, 174

PVR/DVR-SAT Combo Codes

Bell ExpressVu	195	Echostar	195
Dish Network	195	RCA	176

Cable Box Codes

ABC001, 002, 003, 004, 005, 006	Pioneer033, 034, 038
Adelphia136	Pulsar026
Allegro064, 065	RadioShack045, 065, 074
Americast008, 009	RCA000, 047
Antronix008, 009, 010, 011	Realistic009
Archer008, 009, 010, 011	Regal022
AT&T011	Regency017
Cabletenna008	Rembrandt003
Cableview008	Runco026
Century011	Samsung014, 034
Citizen011	Scientific Atlanta006, 036, 037, 038, 075, 136, 147
Colour Voice012, 013	Signal014, 018
Comtronics014, 015	Signature003
Contec/Cony016	SL Marx014
Eastern017	Sprucer000
Garrard011	Standard Components039
GC Electronics009	Starcom001, 018
Gemini018, 019, 076	Stargate014, 018
GE089	Star Sight060
General Instrument003, 049, 051, 053, 054, 058, 068, 069, 070, 071	Star Sight Cable Service047
Hamlin020, 021, 022	Starquest018
Hitachi003	Star Trak056
Hytek002	Tandy040
Jasco011	Televue014
Jerrold001, 003, 004, 005, 018, 024, 049, 050, 051, 066, 068, 069	Telexwest072
Magnavox025	Tocomb039
Memorex026	Toshiba004, 041, 053
Motorola001, 003, 004, 005, 018, 024, 049, 050, 051, 053, 054, 058, 066, 068, 069, 070, 071	Tusa026
Movie Time002, 027	TV86018
NSC002, 027	Unika027
Oak002, 016, 029	United Artists008, 009, 011
Pace072	United Cable002
Panasonic000, 048	Universal001
Paragon026	Viewstar008, 009, 010, 011, 042
Philips011, 012, 013, 019, 025, 030, 031, 032	Videoway044
Philips/Magnavox045, 074	ViewStar015, 025, 027, 040
		Video Tech090
		Zenith026, 028, 043, 057, 059, 060, 061, 062, 063, 064, 065, 067, 073

Audio System Codes

Aiwa179, 182, 191, 200	Pioneer177, 206, 207, 218
Carver165	RadioShack046, 094, 133, 146, 205, 206, 207, 208, 215, 218, 219
Citizen166	RCA057, 112, 121, 135, 167, 185, 206, 207, 210, 211, 212, 215, 218, 219
Denon143, 157	Realistic162
Fisher154, 161	Sanyo045
Goldstar106	Scott108
Harman Kardon144, 158	Sharp011, 037, 149
JVC130, 153, 159	Sherwood046, 159, 198, 199
Kenwood023, 148, 156, 168, 172, 209	Sony118, 137, 138, 139, 173, 174, 175, 176, 183
Magnavox136, 154	Teac050, 147, 195, 196, 197
Marantz028, 164	Technics056, 076, 131, 150, 155, 163, 203, 204
Mitsubishi217	Venturer085
Nad061, 079, 083	Yamaha141, 142, 178, 180, 181, 186, 187, 188, 189
Onkyo145, 151, 152	Zenith016, 070, 089, 099, 105, 106, 124, 154, 190
Optimus007, 087, 088, 089, 091, 092, 094, 133		
Panasonic056, 076, 131, 150, 155, 163, 203, 204		
Philips095, 154, 163, 164, 165		

CD Player Codes

ADC000	NEC030
Adcom001, 054	Nikko005, 013, 016
Aiwa002, 003, 047, 182	NSM006
Akai055, 077, 170	Onkyo035, 036, 062, 151
Audio Technica005	Optimus007, 008, 018, 024, 037, 038, 039, 040, 084, 087, 091
California Audio Labs056	Panasonic056, 073, 080, 160, 202
Capetronic009	Philips006, 071, 165
Carver006, 007, 008, 165	Pioneer018, 041, 042, 059, 090, 177, 216
Casio117	Proton006
Citizen166	Quasar056
Curtis-Mathes117	RadioShack008, 046, 090, 126, 208, 214, 216
Denon010	RCA043, 063, 090, 135, 184, 185, 214, 216
Emerson001, 013	Realistic001, 007, 009, 013, 018, 029, 037, 039
Fisher007, 015, 016, 017, 058	Rotel006
GE065	Sae006
Genexxa013, 018, 059	Samsung081
Goldstar060	Sansui006, 044, 063, 074
Harman Kardon020, 031	Sanyo007, 045, 058, 075, 082
Hitachi018	Scott001, 013
Inkel021	Sears024, 029, 117
JC Penney030, 117	Sharp024, 019, 029
JVC022, 153	Sherwood021, 029, 038, 046, 199
Kenwood019, 023, 025, 067, 068, 168	Shure030
Krell006	Sony047, 048, 132, 134, 140
Kyocera000	STS000
Luxman026, 027, 069, 078	Sylvania006
LXI117	Symphonic049
Magnavox006, 071, 140	Teac016, 029, 039, 049, 050, 051, 196
Marantz006, 028, 029, 072	Technics056, 073, 160, 202
MCS030, 117	Theta Digital071
MGA031	Toshiba061
Mission006	Victor022
Mitsubishi031, 032	Yamaha005, 052, 053, 064, 186
NAD061, 083	Zenith016, 070, 099, 124, 190
Nakamichi033, 034, 171		

Laser Disc Player Codes

Denon.....	.080	Sanyo.....	.007
Pioneer.....	.080	Sony.....	.098
PROSCAN.....	.083	Zenith.....	.007
RCA.....	.083		







