

Code Lists / Liste des codes /
Lista de Códigos

TVs / Téléviseurs

Admiral.....	10093, 10463
Advent.....	10761, 10783, 10815, 10817, 11933
Aiko.....	10092
Akai.....	10812, 11675, 10060, 10702, 10030, 10672, 11676, 11903, 11935, 12078, 12232
Albatron.....	10843
America Action.....	10180
Ampro.....	10751
Anam.....	10180
AOC.....	10030, 11365, 11590
Aomi.....	11623
Apex Digital.....	10156, 10748, 10879, 10765, 11943, 11991
Astar.....	11531, 11738
Audiovox.....	10451, 10180, 10092, 10623, 10802, 10846, 10875, 11284, 11937, 11951, 11952
Aventura.....	10171
Axon.....	11937
Bell & Howell.....	10154, 10016
BenQ.....	11032, 11212, 11315
Boxlight.....	10893
Bradford.....	10180
Broksonic.....	10236, 10463, 10180, 11929, 11935, 11938
Bydsign.....	11309
Candle.....	10030, 10056
Carnivale.....	10030
Carver.....	10054
Celebrity.....	10000
Celera.....	10765
Changhong.....	10765
Citizen.....	10060, 10030, 10092, 10056, 11928, 11935
Clarion.....	10180
Coby.....	12017
Commercial Solutions.....	11447, 10047
Concerto.....	10056
Contec.....	10180
Craig.....	10180
Crosley.....	10000, 10054
Crown.....	10180
Curtis Mathes.....	10047, 10054, 10154, 10451, 10093, 10060, 10702, 10030, 10145, 10166, 10016, 10056, 11147, 10180
CKC.....	11326
Cytron.....	11326
Daewoo.....	10451, 10092, 11661, 10623, 10661, 10672, 11928
Dell.....	11264, 11080, 11178, 11403, 11863
Denon.....	10145
Diamond Vision.....	11996, 11997
Digital Lifestyles.....	11765
DirectV.....	11501
Dumont.....	10017
Durabrand.....	10463, 10180, 10178, 10171
Dwin.....	10093, 10720, 10774
Dynex.....	11463, 11780, 11785, 11810, 12049, 12184
Electroband.....	10000
Electrograph.....	11755, 11623
Electrohome.....	10463
Element.....	11687
Emerson.....	10017, 10154, 10451, 10236, 10463, 10180, 10178, 10171, 10623, 11394, 11665, 11928, 11929, 11944, 11963
Emprex.....	11422, 11765
Envision.....	10030, 10813, 11365
Epson.....	10833, 10840
ESA.....	10812, 10171, 11944, 11963
Fisher.....	10154, 10159
Fujitsu.....	10809, 10683, 10853, 12008
Funai.....	10000, 10180, 10171, 11271, 11963
Futuretech.....	10180
Gateway.....	11755, 11756

GE.....	11447, 10047, 10051, 10451, 10178, 10021, 11347, 11917, 11922
GFM.....	10171, 11665, 11963, 12167
Gibraltar.....	10017, 10030
Go Video.....	10886
GoldStar.....	10178, 10030, 10056, 11926
Grundig.....	10683
Grunpy.....	10180
Haier.....	11748, 11749
Hallmark.....	10178
Hannspree.....	11348, 11351, 11925
HartmanKardon.....	10054
Harsper.....	11206
Harvard.....	10180
Havermy.....	10093
Helios.....	10865
Hello Kitty.....	10451
Hewlett Packard.....	11494, 11502
Hisense.....	10748
Hitachi.....	11643, 11145, 10145, 10016, 10056, 11445, 11960
HP.....	11494, 11502
Humax.....	11501
Hyundai.....	10849
ilo.....	11286, 11603, 11665, 11684, 11990
Infinity.....	10054
Initial.....	11603, 11990
Insignia.....	11423, 11564, 10171, 11204, 11326, 11517, 11641, 11710, 11780, 11892, 11963, 12002, 12049, 12088
Inteq.....	10017
IRIS.....	12189
JBL.....	10054
JCB.....	10000
Jensen.....	10761, 10815, 10817, 11933
JVC.....	10053, 10650, 10731, 11253, 11601, 11774, 11923, 12271
KDS.....	11498, 11687
KEC.....	10180
Kerwood.....	10030
KLH.....	10765
Konka.....	10720
KTV.....	10180, 10030
LG.....	11423, 10017, 11265, 10178, 10856, 11178, 11768, 11993
Logik.....	10016
Luxman.....	10056
LXI.....	10047, 10054, 10154, 10156, 10178
MAG.....	11498, 11687
Magnasonic.....	11928
Magnavox.....	11454, 11866, 11755, 10054, 10051, 10030, 10096, 10802, 11198, 11254, 11365, 11525, 11931, 11944, 11963, 11990
Majestic.....	10016
Marantz.....	11454, 10054, 10030, 10704, 10855, 11154, 11398
Matsushita.....	10250, 10650
Maxent.....	11755, 11714, 11757
Megatron.....	10178, 10145
Memorex.....	10154, 10463, 10150, 10178, 10016, 11903, 11924, 11926, 11927, 11935
MGA.....	10150, 10178, 10030
Midland.....	10047, 10017, 10051
Mintek.....	11603, 11990
Minut.....	10021
Mitsubishi.....	11250, 10093, 10150, 10178, 10836, 10868, 11522, 11971
Monivision.....	10843
Motorola.....	10093, 10835
Moxell.....	10835
MTC.....	10060, 10030, 10056
Multitech.....	10180
NAD.....	10156, 10178, 10056, 10866, 11156
NEC.....	10030, 10056, 10882, 11398, 11704, 11797
NetTV.....	11755
Nexus Electronics.....	12183
Nikko.....	10178, 10030, 10092
Norcent.....	10748, 10824, 11365, 11590
Norwood Micro.....	11286
NTC.....	10092
NuVision.....	11657, 12158

Olevia.....	11610, 11144, 11240, 11331
Onwa.....	10180
Optimus.....	10250, 10154, 10166, 10650, 11924, 11927
Optoma.....	11348
Optonica.....	10093
Orion.....	10236, 10463, 11463, 11929
Panasonic.....	10250, 11480, 11457, 10051, 10030, 10650, 11310, 11410, 11924, 11927, 11941, 11946, 11947, 12080
PARK.....	12194, 12202
Penney.....	10047, 10156, 10051, 10060, 10178, 10030, 10021, 11347, 11926
Petters.....	11523
Philco.....	10054, 10030, 10171, 10096, 11271, 11394, 11665, 11963
Philips.....	11454, 10054, 10690, 11154, 11254, 11744, 11806, 11867
Pilot.....	10030
Pioneer.....	11457, 10166, 10679, 10866, 11260, 11398
Planar.....	11496
Polaroid.....	11523, 10765, 12121, 12120, 12119, 12063, 12002, 11992, 11991, 11769, 11767, 11766, 11687, 11498, 11341, 11328, 11326, 11316, 11314, 11286, 11276, 10865
Portland.....	10451, 10092
Prima.....	10761, 10783, 10815, 10817, 11785, 11933
Prism.....	10051
Proscan.....	11447, 10047, 11347, 11922, 12147, 12256
Proton.....	11320, 11323
Proview.....	10835, 11498, 11687
Pulsar.....	10017
Quasar.....	10250, 10051, 10650, 11924
RadioShack.....	10047, 10154, 10180, 10178, 10030, 10056
RCA.....	11547, 11447, 10047, 10051, 10093, 12247, 12187, 12002, 11958, 11953, 11948, 11922, 11917, 11781, 11347, 11247, 11147, 11047, 10774, 10679
Realistic.....	10154, 10180, 10178, 10030, 10056
RevolutionHD.....	11623
Runco.....	10017, 10030, 11398, 11629
Sampo.....	11755, 10030
Samsung.....	10812, 10054, 10060, 10702, 10178, 10030, 10056, 10650, 10766, 10814, 11060, 11903, 12051
Sansui.....	10463, 10171, 11929, 11935
Sanyo.....	10054, 10154, 10159, 10799, 10893, 11142
Sceptre.....	11360, 11599
Scotch.....	10178
Scott.....	10236, 10180, 10178, 11711
Sears.....	10047, 10054, 10154, 10156, 10178, 10171, 10056, 10159, 11926
Seleco.....	11351
Sharp.....	10818, 10093, 10491, 10851, 11602, 11917
Sheng Chia.....	10093
Signature.....	10016
Sole.....	10813, 11623
Sony.....	10000, 10810, 10834, 11685, 11925
Soundesign.....	10180, 10178
Sova.....	11320, 11952
Soyo.....	11520, 11826
Spectroniq.....	11498, 11687
Squareview.....	10171
SSS.....	10180
Starlite.....	10180
Studio Experience.....	10843
Superscan.....	10093, 10864, 11944
Supreme.....	10000
SV2000.....	10963
SVA.....	10748, 10865
Sylvania.....	11864, 10054, 10030, 10171, 10096, 11271, 11314, 11394, 11665, 11886, 11931, 11944, 11963
Symphonic.....	10180, 10171, 11944
Syntax.....	11610, 11144, 11240, 11331
Tandy.....	10093
Tatung.....	11286, 11756
Technics.....	10250, 10051
Techview.....	10847
Techwood.....	10051, 10056
Teknika.....	10054, 10180, 10150, 10060, 10092, 10016, 10056
Telefunken.....	10702, 10056
TMK.....	10178, 10056

TNCl.....	10017
Toshiba.....	11524, 10154, 10156, 11256, 11265, 10060, 12006, 11945, 11936, 11935, 11918, 11704, 11656, 11635, 11356, 11343, 11156, 10845, 10832, 10650
TruTech.....	11723, 12066
TVS.....	10463
Ultra.....	11323
US Logic.....	11286
Vector Research.....	10030
Victor.....	10053
Vidikron.....	10054, 11398, 11629
Vidtech.....	10178
Viewsonic.....	11755, 10857, 10864, 10885, 11330, 11627, 11742, 12014, 12087
Viore.....	10054, 11684
Vizio.....	11758, 10864, 10885, 11756
Wards.....	10054, 10178, 10030, 10016, 10021, 10056, 10096, 10866, 11156
Waycon.....	10156
Westinghouse.....	10000, 11712, 10451, 10885, 10889, 11282, 11577
White Westinghouse.....	10451, 10463, 10623
Wyse.....	11365
Yamaha.....	10030, 10650, 10769, 10833, 10839
Zenith.....	10000, 11423, 10017, 10463, 11265, 10178, 10030, 11145, 10145, 10092, 10016, 11929

DTV Converters /
Récepteurs TV numériques /
Convertidores Digitales

Access HD.....	02185
Airlink 101.....	02491
Alpha Digital.....	02185
AMTC.....	02185
Apex Digital.....	02478
Artec.....	02490
CASTI.....	02305
Channel Master.....	02365
Coship.....	02487
Daewoo.....	02338
Daytek.....	02305
Digital Stream.....	02303
Dish Network System.....	02470
EchoStar.....	02470
Evolution.....	02479
GE.....	02360, 02450
Goodmind.....	02450
Gridlink.....	02348
Insignia.....	01415
Lasonic.....	02348
Magnavox.....	01563
Memorex.....	02496
MicroGEM.....	02489
Philco.....	01563
RCA.....	02325, 02454
Sansonic.....	02348
Sylvania.....	01563
Tivax.....	02185
Ventura.....	02454
Venturer.....	02454
Winegard.....	02454
Zenith.....	01415
Zentech.....	02491
Zinwell.....	02488

Vídeo Accessories / Accessoires
de vidéo / Acessorios de vídeo

2Wire.....	02045
ABS.....	01272
Access HD.....	02185
Accurian.....	01653
ADB.....	02254, 02586
Airlink 101.....	02491
Alienware.....	01272
Alpha Digital.....	02185
Amino.....	01481, 02482
AMTC.....	02185
Apex Digital.....	02478
Artec.....	02490
AT&T.....	00858, 02045
CASTI.....	02305
Channel Master.....	02365
Cisco.....	02345, 02517
Coship.....	02487
CyberPower.....	01272
Daewoo.....	02338
Daytek.....	02305
Digital Stream.....	02303
Dish Network System.....	02470
EchoStar.....	02470
Entone.....	02302
Epson.....	01563
Evolution.....	02479
Gateway.....	01272
GE.....	02360, 02450
Goodmind.....	02450
Gridlink.....	02348
Hewlett Packard.....	01272, 01267
Howard Computers.....	01272
HP.....	01272
Hush.....	01272
IBUYPOWER.....	01272
Insignia.....	01415
KoolConnect.....	01481
Lasonic.....	02348
LG.....	01415
Linksys.....	01272
Magnavox.....	01563
Media Center PC.....	01272
Memorex.....	02486
MicroGEM.....	02489
Microsoft.....	02049, 01272
Mind.....	01272
Motorola.....	01998, 00858, 01363
Niveus Media.....	01272
Northgate.....	01272
Panasonic.....	01120
Philco.....	01563
Pioneer.....	01010
Popcorn Hour.....	02260
RCA.....	02325, 02454
Ricavision.....	01272
Roku.....	01486, 02371
Samsung.....	01190, 01490
Sansonic.....	02348
Scientific Atlanta.....	00858, 02345, 02517
Sharp.....	01010
Sony.....	01272, 01324, 01364
Stack 9.....	01272
SureWest.....	01481
Sylvania.....	01563
Systemax.....	01272
Tagar Systems.....	01272
Tivax.....	02185
Toshiba.....	01272
Touch.....	01272
Ventura.....	02454

Venturer.....	02454
Verizon.....	02378
Viewsonic.....	01272, 01329
Voodoo.....	01272
Vudu.....	02298
Winegard.....	02454
Xbox.....	02049
Zenith.....	01415
Zentech.....	02491
Zinwell.....	02488
ZT Group.....	01272

Satellite / Satélite

Bell ExpressVu.....	00775, 01170
Coolsat.....	01806
DirectTV.....	01377, 00392, 00566, 00639, 01639, 01142, 00247, 00749, 01749, 00819, 01856, 01076, 01108, 01392, 01414, 01442, 01443, 01609, 01640
Dish Network System.....	00775, 01505, 01775
Dishpro.....	00775, 01505, 01775
Echostar.....	00775, 01505, 01170, 01775
Expressvu.....	00775, 01775
Fortec Star.....	01821
GE.....	00566
General Instrument.....	00869
GOI.....	00775, 01775
Hitachi.....	00819
HTS.....	00775, 01775
Hughes Network Systems.....	01142, 00749, 01749, 01442, 01443
Humax.....	01790
Jerrold.....	00869
JVC.....	00775, 01170, 01775
LG.....	01414
Mitsubishi.....	00749
Motorola.....	00869, 00856
Next Level.....	00869
Panasonic.....	00247, 00701
Pansat.....	01807
Philips.....	01142, 00749, 01749, 01076, 01442
Proscan.....	00392, 00566
RadioShack.....	00869
RCA.....	00392, 00566, 00855, 00143, 01107, 01392
Samsung.....	01377, 01142, 01276, 01108, 01442, 01609
Sony.....	00639, 01639, 01640
Star Choice.....	00869
Tivo.....	01142, 01442, 01443
Toshiba.....	00749, 01749, 00790, 02185
UltimateTV.....	01392, 01640
Ultrasat.....	01806
Voom.....	00869
Zenith.....	01856

Cable / Câble

ABC.....	00003, 00008
Americast.....	00899
Amino.....	01602, 01822
Bell South.....	00899
Cisco.....	01877, 00877, 01982
Comcast.....	01982, 02576
Digeo.....	01187, 02187
Director.....	00476
General Instrument.....	00476, 00810, 00003
Homecast.....	02301
i3 Micro.....	01602
Jerrold.....	00476, 00810, 00003
Memorex.....	00000
Motorola.....	01376, 00476, 00810, 01187, 01106, 01951
MTS.....	01951
Myrio.....	01602, 01822
Pace.....	01877, 00237, 00008
Panasonic.....	00000, 00107, 01982
Paragon.....	00000

Philips.....	01305
Pioneer.....	01877, 00877
Pulsar.....	00000
Quasar.....	00000
RCA.....	01256
Runco.....	00000
Scientific Atlanta.....	01877, 00877, 00008
Sejin.....	01602
Starcom.....	00003
Thomson.....	01256
Tivo.....	02576
Torx.....	00003
Toshiba.....	00000
Zenith.....	00000, 00899

VCRs / Magnétoscopes

ABS.....	21972
Accurian.....	20000
Admiral.....	20048
Adventure.....	20000
Aiko.....	20278
Aiwa.....	20037, 20000
Alienware.....	21972
Allegro.....	20039
America Action.....	20278
American High.....	20035
Audiovox.....	20037, 20278
Broksonic.....	21479
Calix.....	20037
Canon.....	20035
Carver.....	20081
CCE.....	20278
Citizen.....	20037, 20278, 21278
Craig.....	20037
Crosley.....	20081, 20000
Curtis Mathes.....	20060, 20035, 20162, 20278, 21035
CyberPower.....	21972
Daewoo.....	20045, 20278, 21278
Dell.....	21972
Denon.....	20042
DirectV.....	20739
Durabrand.....	20039, 20038
Sony.....	20000
Dynatech.....	20037, 20043
Electrohome.....	20037
Electrophonic.....	20037
Emerex.....	20032
Emerson.....	20037, 20000, 20043, 20278, 20593, 21278, 21479, 21593
Fuji.....	20035, 20033
Funai.....	20000, 20593, 21593
Garrard.....	20000
Gateway.....	21972
GE.....	20060, 20035, 20202, 20807, 21035, 21060
GFM.....	21593
Go Video.....	20614
GoldStar.....	20037, 20038, 21237
Gradiente.....	20000
Harley Davidson.....	20000
Harman/Kardon.....	20081, 20038
Headquarter.....	20046
Hewlett Packard.....	21972
Hitachi.....	20000, 20042
STS.....	20042
Sylvania.....	20035, 20081, 20000, 20043, 20593, 21593, 21781
HP.....	21972
Symphonic.....	20000, 20593, 21593
Systemax.....	21972
Tagar Systems.....	21972
Hush.....	20037
Tashiko.....	20037
Teac.....	20000
Technics.....	20035, 20162
Teknika.....	20035, 20037, 20000
Thomas.....	20000
Tivo.....	20739, 20618, 20636, 21996
Kodak.....	20045, 20043, 20845, 21008, 21145, 21972, 21996

Linksys.....	21972
Pioneer.....	20000
LXI.....	20037
Magnasonic.....	20593, 21278
Magnavox.....	20035, 20039, 20081, 20000, 20563, 20593, 21593, 21781
Marantz.....	20035, 20081
Marta.....	20037
Matsushita.....	20035, 20162, 21162
Media Center PC.....	21972
MEI.....	20035
Memorex.....	20035, 20162, 20037, 20048, 20039, 20000, 20046, 21162, 21237, 21262
MGA.....	20043
Microsoft.....	21972
Mind.....	21972
Minolta.....	20042
Mitsubishi.....	20067, 20043, 20807
Motorola.....	20035, 20048
MTC.....	20000
Multitech.....	20000
NEC.....	20067, 20038
Nikko.....	20037
Niveus Media.....	21972
Northgate.....	21972
Olympus.....	20035
Optimus.....	21062, 20162, 20037, 20048, 20593, 21048, 21162, 21262
Orion.....	21479
Panasonic.....	21062, 20035, 20162, 20614, 20616, 21035, 21162, 21262
Penney.....	20035, 20037, 20042, 20038, 21035, 21237
Pentax.....	20042
Philco.....	20035
Philips.....	20739, 20035, 20081, 20618, 21081, 21181
Pilot.....	20037
Pioneer.....	20067
Polk Audio.....	20081
Portland.....	20278
Presidian.....	21593
Proscan.....	20060, 20202, 21060
Pulsar.....	20039
Quarter.....	20046
Quartz.....	20046
Quasar.....	20035, 20162, 21035, 21162
RadioShack.....	20000
Radix.....	20037
Randex.....	20037
RCA.....	20060, 20042, 20202, 20807, 20880, 21035, 21060
Realistic.....	20035, 20037, 20048, 20000, 20046
ReplayTV.....	20614, 20616
Ricavision.....	21972
Runco.....	20039
Samsung.....	20739, 20045, 21014
Sanky.....	20048, 20039
Sansui.....	20000, 20067, 21479
Sanyo.....	20046
Scott.....	20045, 20043
Sears.....	20035, 20037, 20000, 20042, 20046, 21237
Sharp.....	20048, 20807, 20848
Sonic Blue.....	20614, 20616
Sony.....	21232, 20032, 20035, 20033, 20000, 20636, 21032, 21972
Stack 9.....	21972
ST.....	20042
Sylvania.....	20035, 20081, 20000, 20043, 20593, 21593, 21781
Symphonic.....	20000, 20593, 21593
Systemax.....	21972
Tagar Systems.....	21972
Tashiko.....	20037
Teac.....	20000
Technics.....	20035, 20162
Teknika.....	20035, 20037, 20000
Thomas.....	20000
Tivo.....	20739, 20618, 20636, 21996
Toshiba.....	20045, 20043, 20845, 21008, 21145, 21972, 21996

Totevision.....	20037
Touch.....	21972
Vector.....	20045
Vector Research.....	20038
Video Concepts.....	20045
Videomagic.....	20037
Viewsonic.....	21972
Villain.....	20000
Voodoo.....	21972
Wards.....	20060, 20035, 20048, 20081, 20000, 20042
XR-1000.....	20035, 20000
Yamaha.....	20038
Zenith.....	20039, 20033, 20000, 21479
ZT Group.....	21972

DVD / Lecteurs DVD

Accurian.....	30675, 21416
Aiwa.....	20533, 20641
Akai.....	20695, 20899
Alco.....	20790
Allegro.....	20869
Apex Digital.....	20672, 20717, 20794, 20796, 20797, 20830, 21004, 21020, 21056, 21061, 21100, 21480
Arrgo.....	21023
Audiovox.....	20790, 21041, 21121, 21122
BBK.....	21224
Bel Canto Design.....	21571
Blaupunkt.....	20717
Blue Parade.....	20571
Bose.....	21895, 22023
Broksonic.....	20695, 20868, 21419
Buffalo.....	21882
California Audio Labs.....	20490
Cinea.....	20831
CineVision.....	20869
Citizen.....	20695
Coby.....	20778, 21086, 21107, 21177
Craig.....	20831
Curtis Mathes.....	21087
CyberHome.....	20816, 20874, 21023, 21024, 21129, 21502, 21537
D-Link.....	21881
Daewoo.....	20784, 20869, 21169, 21172, 21443
Denon.....	20490, 22258
Diamond Vision.....	21316
DigitalMax.....	21738
Disney.....	20675, 21270
Durabrand.....	21023, 21127, 22164
DVD2000.....	20521
Emerson.....	20591, 20675, 20821, 21268
Enterprise.....	20591
ESA.....	20821, 21268, 21443
Fisher.....	20670
Funai.....	20675, 21268, 21334
Gateway.....	21077, 21158
GE.....	20522, 20815, 20717
GFM.....	20675, 21268
Go Video.....	20744, 20715, 20741, 20783, 20869, 21044, 21075, 21158, 21443, 21730
GoldStar.....	20741, 20869
Gradiente.....	20490
Greenhill.....	20717
Grundig.....	20539
Harman/Kardon.....	20582, 20702, 21229
Helios.....	22192
Hello Kitty.....	20831
Hitachi.....	20573, 20664
Hiteker.....	20672
Humax.....	21588
iLo.....	21348, 21472
Initial.....	20717, 21472
Insignia.....	20675, 21268, 21712, 22095, 22428
Integra.....	20571, 20627, 21769, 22147
JBL.....	20702
JSI.....	21423
JVC.....	20558, 20623, 20867, 21164, 21275, 21550, 21602, 21863

Kawasaki.....	20790
Kenwood.....	20490, 20534
KLH.....	20717, 20790, 21020, 21149
Konka.....	20711
Koss.....	20651, 21423
Lasonic.....	20798
Lecson.....	21533
Lenox.....	21127
LG.....	20591, 20741, 20869
LiteOn.....	21058, 21158, 21416, 21440, 21656, 21738
Magnavox.....	20503, 20539, 20646, 20675, 20821, 21268, 21354, 21472, 21506
Marantz.....	20539, 22414
McIntosh.....	21533, 21273
Memorex.....	20695, 20831, 21270, 22213
Microsoft.....	20522, 22083
Mintek.....	20839, 20717, 21472
Mitsubishi.....	21521, 20521
NAD.....	20741
Nesa.....	20717
NexTech.....	21402
Norcent.....	21107
Olevia.....	22331
Onkyo.....	20503, 20627, 21769, 22147
Oppo.....	20575, 21224, 22185
Ortron.....	20651
Panasonic.....	20490, 20503, 20632, 20703, 21362, 21462, 21490, 21641, 21762, 21907, 22017
Philco.....	20675
Philips.....	20503, 20539, 22056, 20646, 20675, 20854, 21158, 21260, 21267, 21380, 21354, 21506, 22084, 22334, 22434
PianoDisc.....	21024
Pioneer.....	20525, 20571, 20142, 20631, 20632, 21460, 21571, 22442
Polaroid.....	21020, 21061, 21086, 21316, 21478, 21480, 21482, 22313
Polk Audio.....	20539
Presidian.....	20675, 21738
Procede.....	20672
Proscan.....	20522
ProVision.....	20778
Qvestar.....	20651
RCA.....	20522, 20571, 20717, 20790, 20822, 21022, 21132, 21769, 22292
Rio.....	20869
Rotel.....	20623
Sampo.....	20752
Samsung.....	20490, 20573, 20744, 20199, 20820, 20899, 21044, 21075, 21932, 22329
Sansui.....	20695
Sanyo.....	20670, 20695, 20873
Schmartz.....	22367
Sensory Science.....	21158
Sharp.....	20630, 20675, 20752, 21256, 21419, 22250, 22477
Sherwood.....	21077, 21889
Sherwood Newcastle.....	21077
Shinsonic.....	20533, 20839
Sonic Blue.....	20869
Sony.....	20533, 21533, 20864, 21033, 21070, 21431, 21516, 22020
Sova.....	21122
Superscan.....	20675, 20821, 21268, 22194
Sylvania.....	20675, 20821, 21268
Teac.....	20790
Technics.....	20490, 20703
Theta Digital.....	20571
Tivo.....	20503, 20695, 21045, 21154, 21503, 21588
Toshiba.....	20503, 20695, 21045, 21154, 21503, 21510, 21588, 21769, 21854, 22006, 22277
Urban Concepts.....	20503
US Logic.....	20839
Venturer.....	20790
Vizio.....	21064, 21226
Xbox.....	20522, 22083
Yamaha.....	20490, 20539, 20646, 20545
Zenith.....	20503, 20591, 20741, 20869

Trademark(s) © Registered
Marque(s) de commerce déposée(s)© Marca(s) Registrada(s)
OARCDAG Codes 00