

Code Lists / Liste des codes /
Lista de Códigos

Audio

Amplifier / Amplificateur / Amplificador

Nova.....	1389
Onkyo.....	0842, 1298, 1320, 1531, 1805
Optimus.....	1023, 0531, 1074
Panasonic.....	1308, 1518, 1275, 1288, 1316, 1548, 1633, 1763, 1764, 2967
Philips.....	1189, 1269, 1266, 2311
Pioneer.....	1023, 0014, 0150, 0531, 0630, 1384, 1935
Polaroid.....	1508
Polk Audio.....	1289
Proscan.....	1254
RCA.....	1023, 1609, 1254, 0346, 0531, 1074, 1390, 1511, 2041
Rio.....	1869
Samsung.....	1295, 1500, 1868
Sansui.....	0346
Sanyo.....	1469, 1801
Sherwood.....	1077, 1517, 1653, 1905, 2169
Sherwood Newcastle.....	2169
Sonic Blue.....	1869
Sony.....	1759, 1058, 1441, 1258, 1622, 1558, 1658, 1758, 1822, 1858, 2172
Stereophonics.....	1023
Sunfire.....	1313
Teac.....	1074, 1390
Technics.....	1308, 1518
Thorens.....	1189
Venturer.....	1390
Vizio.....	1517
Wards.....	0014
Yamaha.....	0176, 1176, 1276, 1331, 1375, 1376, 1476, 2061
Zenith.....	0857, 1293

CD Players / Lecteurs CD / Reproductores de CDs

Aiwa.....	0157
Burmester.....	0420
California Audio Labs.....	0029, 0303
Carver.....	0157, 0179
Classic.....	1297
Denon.....	0003
DKK.....	0000
DMX Electronics.....	0157
Emerson.....	0305
Fisher.....	0179, 1325
Garrard.....	0393, 0420
Genexxa.....	0032, 0305
GPX.....	1296
Harman/Kardon.....	0157, 0173, 1202
Hitachi.....	0032
Integra.....	0101
JVC.....	0072, 1294
Kenwood.....	0626, 0028, 0037, 0190
KLH.....	1318
Koss.....	1317
Krell.....	0157
LG.....	1208
Linn.....	0157
LXI.....	0305
Magnavox.....	0157, 0305
Marantz.....	0626, 0029, 0157, 0180
Mark Levinson.....	1484
MCS.....	0029
Miro.....	0000
Mission.....	0157
MTC.....	0420
NAD.....	1298, 1320, 1805
NSM.....	0157
Onkyo.....	0101
Optimus.....	0000, 0032, 0037, 0087, 0145, 0179, 0305, 0420, 0468
Panasonic.....	0029, 0303, 0752
Parasound.....	0420
Philips.....	0626, 0157
Pioneer.....	1062, 0032, 1087, 0305, 0468
Polk Audio.....	0157
Proton.....	0157
QED.....	0157
Quad.....	0157

CD Recorders / Enregistreurs CD / Grabadora de discos CD

Classic.....	1297
Fisher.....	1325
GPX.....	1296
Harman/Kardon.....	1202
JVC.....	1294
Kenwood.....	0626
LG.....	1208
Marantz.....	0626
NAD.....	1208
Philips.....	0626
Pioneer.....	1062, 1087
RCA.....	0053, 0420
Sony.....	0000, 0100, 1364
TDK.....	1208
Teac.....	0420
Yamaha.....	1292

Audio Accessories / Accessoires de audio /
Accesorios de audio

Accurian.....	1106
Altec Lansing.....	0607
Apple.....	1115
DLO.....	1155
GPX.....	2113
Griffin.....	1891
iDeck.....	1106
iHome.....	2152
iLive.....	2113
Memorex.....	2119
Monitor Audio.....	1106
Polk Audio.....	2228
Roku.....	1828
Yamaha.....	2021

Media Centers / Centres de médias /
Centros de entretenimiento

ABS.....	1272
Alienware.....	1272
Apple.....	1115
CyberPower.....	1272
Gateway.....	1272
Hewlett Packard.....	1272
Howard Computers.....	1272
HP.....	1272
Hush.....	1272

Video Accessories / Accessoires
de vidéo / Acessorios de vídeo

2Wire.....	2045
AB5.....	1272
Access HD.....	2185
ADB.....	2254, 2586
Airlink 101.....	2491
Alienware.....	1272
Alpha Digital.....	2185
Amino.....	1481, 2482
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
AT&T.....	0858, 2045
CASTI.....	2305
Channel Master.....	2365
Cisco.....	2345
Coship.....	2487
CyberPower.....	1272
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Entone.....	2302
Epson.....	1563
Evolution.....	2479
Gateway.....	1272
GE.....	2360, 2450
Goodmind.....	2450
Gridlink.....	2348
Hewlett Packard.....	1272, 1267
Howard Computers.....	1272
HP.....	1272
Hush.....	1272
iBUYPOWER.....	1272
Insignia.....	1415
KoolConnect.....	1481
Lasonic.....	2348
LG.....	1415
Linksys.....	1272
Magnavox.....	1563
Media Center PC.....	1272
Memorex.....	2486
MicroGEM.....	2489
Microsoft.....	2049, 1272
Mind.....	1272
Motorola.....	1998, 0858, 1363, 2378
Niveus Media.....	1272
Northgate.....	1272
Panasonic.....	1120
Philco.....	1563
Pioneer.....	1010
Popcorn Hour.....	2260
RCA.....	2325, 2454
Ricavision.....	1272
Roku.....	1486, 2371
Samsung.....	1190, 1490
Sansonic.....	2348
Scientific Atlanta.....	0858, 2345
Sharp.....	1010
Sony.....	1272, 1324, 1364
Stack 9.....	1272
Sansonic.....	2348
Sylvania.....	1563
Tivax.....	2185
Ventura.....	2454
Venturer.....	2454
Winegard.....	2454
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2488

Controlled by VCR key / Contrôlé par la touche VCR /
Controlado por la tecla VCR

CyberPower.....	1972
Gateway.....	1972
Hewlett Packard.....	1972
iBUYPOWER.....	1972
Microsoft.....	1972
Northgate.....	1972
Tagar Systems.....	1972
Touch.....	1972

DTV Converters /
Récepteurs TV numériques /
Convertidores Digitales

Access HD.....	2185
Airlink 101.....	2491
Alpha Digital.....	2185
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
CASTI.....	2305
Channel Master.....	2489
Microsoft.....	2049, 1272
Mind.....	1272
Niveus Media.....	1998, 0858, 1363, 2378
Northgate.....	1272
Panasonic.....	1120
Philco.....	1563
Pioneer.....	1010
Popcorn Hour.....	2260
RCA.....	2325, 2454
Ricavision.....	1272
Roku.....	1486, 2371
Samsung.....	1190, 1490
Sansonic.....	2348
Scientific Atlanta.....	0858, 2345
Sharp.....	1010
Sony.....	1272, 1324, 1364
Stack 9.....	1272
Sansonic.....	2348
Sylvania.....	1563
Tivax.....	2185
Ventura.....	2454
Venturer.....	2454
Winegard.....	2454
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2488

Controlled by VCR key / Contrôlé par la touche VCR /
Controlado por la tecla VCR

CyberPower.....	1972
Gateway.....	1972
Hewlett Packard.....	1972
iBUYPOWER.....	1972
Microsoft.....	1972
Northgate.....	1972
Tagar Systems.....	1972
Touch.....	1972

Video Accessories / Accessoires
de vidéo / Acessorios de vídeo

2Wire.....	2045
AB5.....	1272
Access HD.....	2185
ADB.....	2254, 2586
Airlink 101.....	2491
Alienware.....	1272
Alpha Digital.....	2185
Amino.....	1481, 2482
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
AT&T.....	0858, 2045
CASTI.....	2305
Channel Master.....	2365
Cisco.....	2345
Coship.....	2487
CyberPower.....	1272
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Entone.....	2302
Epson.....	1563
Evolution.....	2479
Gateway.....	1272
GE.....	2360, 2450
Goodmind.....	2450
Royal Sovereign.....	1651
Russound.....	1232, 1233, 1413
Security System.....	0167
Sharper Image.....	0846
SmartLinc.....	0184, 1204, 1205, 1206
Universal X10.....	0167
Whirlpool.....	1332
Windmere.....	1215
X10.....	0167, 2267

Controlled by VCR key / Contrôlé par la touche VCR /
Controlado por la tecla VCR

CyberPower.....	1972
Gateway.....	1972
Hewlett Packard.....	1972
iBUYPOWER.....	1972
Microsoft.....	1972
Northgate.....	1972
Tagar Systems.....	1972
Touch.....	1972

Video Accessories / Accessoires
de vidéo / Acessorios de vídeo

2Wire.....	2045
AB5.....	1272
Access HD.....	2185
ADB.....	2254, 2586
Airlink 101.....	2491
Alienware.....	1272
Alpha Digital.....	2185
Amino.....	1481, 2482
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
AT&T.....	0858, 2045
CASTI.....	2305
Channel Master.....	2365
Cisco.....	2345
Coship.....	2487
CyberPower.....	1272
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Entone.....	2302
Epson.....	1563
Evolution.....	2479
Gateway.....	1272
GE.....	2360, 2450
Goodmind.....	2450
Gridlink.....	2348
Hewlett Packard.....	1272, 1267
Howard Computers.....	1272
HP.....	1272
Hush.....	1272
iBUYPOWER.....	1272
Insignia.....	1415
KoolConnect.....	1481
Lasonic.....	2348
LG.....	1415
Linksys.....	1272
Magnavox.....	1563
Media Center PC.....	1272
Memorex.....	2486
MicroGEM.....	2489
Microsoft.....	2049, 1272
Mind.....	1272
Motorola.....	1998, 0858, 1363, 2378
Niveus Media.....	1272
Northgate.....	1272
Panasonic.....	1120
Philco.....	1563
Pioneer.....	1010
Popcorn Hour.....	2260
RCA.....	2325, 2454
Ricavision.....	1272
Roku.....	1486, 2371
Samsung.....	1190, 1490
Sansonic.....	2348
Scientific Atlanta.....	0858, 2345
Sharp.....	1010
Sony.....	1272, 1324, 1364
Stack 9.....	1272
Sansonic.....	2348
Sylvania.....	1563
Tivax.....	2185
Ventura.....	2454
Venturer.....	2454
Winegard.....	2454
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2488

Controlled by VCR key / Contrôlé par la touche VCR /
Controlado por la tecla VCR

CyberPower.....	1972
Gateway.....	1972
Hewlett Packard.....	1972
iBUYPOWER.....	1972
Microsoft.....	1972
Northgate.....	1972
Tagar Systems.....	1972
Touch.....	1972

Video Accessories / Accessoires
de vidéo / Acessorios de vídeo

2Wire.....	2045
AB5.....	1272
Access HD.....	2185
ADB.....	2254, 2586
Airlink 101.....	2491
Alienware.....	1272
Alpha Digital.....	2185
Amino.....	1481, 2482
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
AT&T.....	0858, 2045
CASTI.....	2305
Channel Master.....	2365
Cisco.....	2345
Coship.....	2487
CyberPower.....	1272
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Entone.....	2302
Epson.....	1563
Evolution.....	2479
Gateway.....	1272
GE.....	2360, 2450
Goodmind.....	2450
Royal Sovereign.....	1651
Russound.....	1232, 1233, 1413
Security System.....	0167
Sharper Image.....	0846
SmartLinc.....	0184, 1204, 1205, 1206
Universal X10.....	0167
Whirlpool.....	1332
Windmere.....	1215
X10.....	0167, 2267

Controlled by VCR key / Contrôlé par la touche VCR /
Controlado por la tecla VCR

CyberPower.....	1972
Gateway.....	1972
Hewlett Packard.....	1972
iBUYPOWER.....	1972
Microsoft.....	1972
Northgate.....	1972
Tagar Systems.....	1972
Touch.....	1972

Video Accessories / Accessoires
de vidéo / Acessorios de vídeo

2Wire.....	2045
AB5.....	1272
Access HD.....	2185
ADB.....	2254, 2586
Airlink 101.....	2491
Alienware.....	1272
Alpha Digital.....	2185
Amino.....	1481, 2482
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
AT&T.....	0858, 2045
CASTI.....	2305
Channel Master.....	2365
Cisco.....	2345
Coship.....	2487
CyberPower.....	1272
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Entone.....	2302
Epson.....	1563
Evolution.....	2479
Gateway.....	1272
GE.....	2360, 2450
Goodmind.....	2450
Royal Sovereign.....	1651
Russound.....	1232, 1233, 1413
Security System.....	0167
Sharper Image.....	0846
SmartLinc.....	0184, 1204, 1205, 1206
Universal X10.....	0167
Whirlpool.....	1332
Windmere.....	1215
X10.....	0167, 2267

Controlled by VCR key / Contrôlé par la touche VCR /
Controlado por la tecla VCR

CyberPower.....	1972
Gateway.....	1972
Hewlett Packard.....	1972
iBUYPOWER.....	1972
Microsoft.....	1972
Northgate.....	1972
Tagar Systems.....	1972
Touch.....	1972

Video Accessories / Accessoires
de vidéo / Acessorios de vídeo

2Wire.....	2045
AB5.....	1272
Access HD.....	2185
ADB.....	2254, 2586
Airlink 101.....	2491
Alienware.....	1272
Alpha Digital.....	2185
Amino.....	1481, 2482
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
AT&T.....	0858, 2045
CASTI.....	2305
Channel Master.....	2365
Cisco.....	2345
Coship.....	2487
CyberPower.....	1272
Daewoo.....	23

