



Cable	ABC	0003 0008 0014 0007 0001 0011 0013 0017
Cable	Allegro	0153 0315
Cable	Americast	0899
Cable	Antronix	0022 0207
Cable	Apache	0770
Cable	Archer	0022 0153 0207 0797
Cable	BBT	0267
Cable	Belcor	0056
Cable	Bell & Howell	0014
Cable	Bell South	0899
Cable	Cable Star	0056
Cable	Cabletenna	0022
Cable	Cableview	0022
Cable	Century	0153
Cable	Citizen	0153 0315
Cable	Colour Voice	0025 0031
Cable	Comband	0232
Cable	Comtronics	0040 0060
Cable	Contec	0019
Cable	Digi	0637
Cable	Director	0476
Cable	Eastern	0002
Cable	Emerson	0797
Cable	Everquest	0015 0040
Cable	Focus	0400
Cable	GC Electronics	0056 0207
Cable	GE	0232
Cable	Garrard	0153
Cable	Gemini	0015 0070 0242 0797
Cable	General Instrument	0476 0003 0276 0011 0810
Cable	GoldStar	0144 0040
Cable	Goodmind	0770 0797
Cable	Hamlin	0009 0020 0034 0259 0273
Cable	Hitachi	0011
Cable	Hytex	0007
Cable	Jasco	0015 0153 0315
Cable	Jerrold	0476 0003 0276 0012 0014 0015 0011 0024 0810
Cable	Linsay	0440
Cable	Magnavox	0027
Cable	Memorex	0000
Cable	Motorola	0476 1106 0276 0810
Cable	Movie Time	0063 0156
Cable	NSC	0063 0070 0156
Cable	Nexus	0770

Cable	Novaplex	0618
Cable	Oak	0019 0007
Cable	Optimus	0021
Cable	Panasonic	0000 0107 0021
Cable	Panther	0637
Cable	Paragon	0000
Cable	Philips	0305 0317 0025 0027 0031 0153 0242 0290
Cable	Pioneer	0877 0144 0533 0023
Cable	Popular Mechanics	0400
Cable	Prelude	0770
Cable	Pulsar	0000
Cable	Quasar	0000
Cable	RCA	0021
Cable	RadioShack	0015 0315 0797 0883
Cable	Realistic	0207
Cable	Recoton	0400
Cable	Regal	0020 0259 0273
Cable	Regency	0002
Cable	Rembrandt	0011 0070
Cable	Runco	0000
Cable	SL Marx	0040
Cable	Samsung	0144 0040
Cable	Scientific Atlanta	0877 0008 0006 0017 0477
Cable	Seam	0510
Cable	Signal	0015 0040
Cable	Signature	0011
Cable	Sprucer	0021
Cable	StarSight	0422 0542
Cable	Starcom	0003 0015
Cable	Stargate	0015 0040 0770 0797
Cable	Starquest	0015
Cable	Supercable	0276
Cable	Sylvania	0001
Cable	TFC	0310
Cable	TV86	0063
Cable	Tandy	0258
Cable	TeleCaption	0221
Cable	Televue	0040
Cable	Texscan	0001
Cable	Timeless	0418
Cable	Tocom	0012 0013
Cable	Torx	0003
Cable	Toshiba	0000
Cable	Tusa	0015
Cable	Unika	0022 0153 0207
Cable	United Artists	0007

Cable	Universal	0022 0056 0153 0191 0207
Cable	ViewMaster	0883
Cable	Viewstar	0027 0060 0063 0258
Cable	Zenith	0000 0525 0899 0054
Cable	Zentek	0400
DVD	Aiwa	0641
DVD	Apex	0672
DVD	Apex Digital	0794 0795 0796 0797 0755 0717 0830 0856
DVD	B & K	0655 0662
DVD	Denon	0490 0634
DVD	Fisher	0670
DVD	GE	0522 0717
DVD	Gradiente	0651
DVD	Greenhill	0717
DVD	Harman/Kardon	0582
DVD	Hitachi	0573 0664
DVD	Hiteker	0672
DVD	JVC	0558 0623
DVD	KLH	0717
DVD	Kenwood	0534 0682
DVD	Konka	0711 0719 0720 0721
DVD	Magnavox	0503
DVD	Magnavox	0675
DVD	Marantz	0539
DVD	Mintek	0717
DVD	Mitsubishi	0521
DVD	Nesa	0717
DVD	Onkyo	0503 0627
DVD	Optimus	0571
DVD	Oritron	0651
DVD	Panasonic	0490 0632 0677 0678 0679
DVD	Philips	0503 0539
DVD	Pioneer	0525 0571 0632
DVD	Princeton	0674
DVD	Proscan	0522
DVD	RCA	0522 0571 0717
DVD	Samsung	0573
DVD	Sharp	0630
DVD	Sherwood	0633
DVD	Sony	0533
DVD	Technics	0490
DVD	Techwood	0692
DVD	Theta Digital	0571
DVD	Toshiba	0503
DVD	Yamaha	0490 0545
DVD	Zenith	0503 0591

Satellite	AlphaStar	0772
Satellite	Crossdigital	1109
Satellite	DishPro	1005 0775
Satellite	Echostar	1005 0775
Satellite	Expressvu	0775
Satellite	GE	0566
Satellite	GOI	0775
Satellite	General Instrument	0869 0361 0627
Satellite	HTS	0775
Satellite	Hitachi	0819
Satellite	Hughes Network Systems	0749
Satellite	JVC	0775
Satellite	Jerrold	0361 0627
Satellite	Magnavox	0724 0722
Satellite	Memorex	0724
Satellite	Mitsubishi	0749
Satellite	Motorola	0869
Satellite	Next Level	0869
Satellite	Panasonic	0701
Satellite	Paysat	0724
Satellite	Philips	0749 0724 1076 0722
Satellite	Primestar	0361 0627
Satellite	Proscan	0392
Satellite	RCA	0392 0566 0855 0143
Satellite	RadioShack	0869
Satellite	SKY	0856
Satellite	Samsung	1109
Satellite	Sony	0639
Satellite	Star Choice	0869
Satellite	Toshiba	0749 0790
Satellite	Uniden	0724 0722
Satellite	Zenith	0856
TV	AOC	0030 0019 0185
TV	Admiral	0093 0463
TV	Aiko	0092
TV	Akai	0030
TV	Alaron	0179
TV	Ambassador	0177
TV	America Action	0180
TV	Ampro	0751
TV	Anam	0180
TV	Anam National	0055
TV	Apex Digital	0748 0765 0767
TV	Audiovox	0451 0180 0092 0623
TV	Baysonic	0180
TV	Belcor	0019
TV	Bell & Howell	0154 0016

TV	Bradford	0180
TV	Brockwood	0019
TV	Broksonic	0236 0463
TV	CXC	0180
TV	Candle	0030 0056
TV	Carnivale	0030
TV	Carver	0054
TV	Celebrity	0000
TV	Changhong	0765
TV	Cineral	0451 0092
TV	Citizen	0060 0030 0056 0092
TV	Clairtone	0185
TV	Concerto	0056
TV	Contec	0180 0185
TV	Craig	0180
TV	Crosley	0054
TV	Crown	0180
TV	Curtis Mathes	0047 0054 0154 0451 0093 0060 0030 0145 0056 0016 0166 0466 0747 1147 1347
TV	Daewoo	0451 0019 0092 0623
TV	Daytron	0019
TV	Denon	0145
TV	Dumont	0017 0019
TV	Durabrand	0003 0171 0178 0180 0463 1034
TV	Dwin	0720 0774
TV	Electroband	0000 0185
TV	Emerson	0154 0236 0463 0180 0282 0178 0019 0179 0177 0185 0623
TV	Envision	0030
TV	Fisher	0154 0159
TV	Fujitsu	0179 0683
TV	Funai	0180 0179 0171
TV	Futuretech	0180
TV	GE	0047 0051 0451 0282 0178 0021 0055 0747 1147 1347
TV	Gibraltar	0017 0030 0019
TV	GoldStar	0030 0178 0019
TV	Gradiente	0053 0056
TV	Grunpy	0180 0179
TV	Hallmark	0178
TV	Harley Davidson	0179
TV	Harman/Kardon	0054
TV	Harvard	0180
TV	Havermy	0093
TV	Hitachi	0145 0056 0016 0151
TV	Infinity	0054

TV	Inteq	0017
TV	JBL	0054
TV	JCB	0000
TV	JVC	0053
TV	KEC	0180
TV	KTV	0180 0030 0185
TV	Kenwood	0030 0019
TV	Konka	0628 0632 0638 0703 0707
TV	LG	0056
TV	LXI	0047 0054 0154 0156 0178 0747
TV	Logik	0016
TV	Luxman	0056
TV	MEI	0185
TV	MGA	0150 0030 0178 0019
TV	MTC	0060 0030 0019 0056 0185
TV	Magnavox	0054 0030 0179 0187 1254
TV	Majestic	0016
TV	Marantz	0054 0030
TV	Matsushita	0250
TV	Megatron	0178 0145
TV	Memorex	0154 0250 0463 0150 0178 0179 0016
TV	Midland	0047 0017 0051 0747
TV	Minutz	0021
TV	Mitsubishi	0093 0150 0178 0019
TV	Motorola	0093 0055
TV	Multitech	0180
TV	NAD	0156 0178 0166
TV	NEC	0030 0019 0056
TV	NTC	0092
TV	Nikko	0030 0178 0092
TV	Noshi	0018
TV	Onwa	0180
TV	Optimus	0154 0250 0166
TV	Optonica	0093 0165
TV	Orion	0236 0463 0179
TV	Panasonic	0250 0051 0055
TV	Penney	0047 0156 0051 0060 0030 0178 0021 0019 0018 0747 1347
TV	Philco	0054 0463 0030 0145 0019
TV	Philips	0054 1354
TV	Pilot	0030 0019
TV	Pioneer	0166 0679
TV	Portland	0019 0092
TV	Princeton	0717
TV	Prism	0051

TV	Proscan	0047 0747
TV	Proton	0178 0466
TV	Pulsar	0017 0019
TV	Quasar	0250 0051 0165 0055
TV	RCA	0047 0019 0018 0090 0679 0747 1047 1147 1247 1347 1447
TV	RadioShack	0047 0154 0165 0180 0030 0178 0019 0056 0747
TV	Realistic	0154 0165 0180 0030 0178 0019 0056
TV	Rhapsody	0185
TV	Runco	0017 0030 0603
TV	SSS	0180 0019
TV	Sampo	0030
TV	Samsung	0060 0030 0178 0019 0056
TV	Sansei	0451
TV	Sansui	0463
TV	Sanyo	0154 0159
TV	Scimitsu	0019
TV	Scotch	0178
TV	Scott	0236 0180 0178 0019 0179
TV	Sears	0047 0054 0154 0156 0178 0179 0056 0159 0171 0747
TV	Semivox	0180
TV	Semp	0156
TV	Sharp	0093 0165 0688
TV	Shogun	0019
TV	Signature	0016
TV	Simpson	0187
TV	Sony	0000
TV	Soundesign	0180 0178 0179
TV	Squareview	0171
TV	Starlite	0180
TV	Supreme	0000
TV	Sylvania	0054 0030 0171
TV	Symphonic	0180 0171
TV	TMK	0178 0056 0177
TV	TNCi	0017
TV	Tandy	0093
TV	Tatung	0055
TV	Technics	0250 0051
TV	Technol Ace	0179
TV	Techwood	0051 0056
TV	Teknika	0054 0180 0150 0060 0019 0179 0056 0016 0092
TV	Telefunken	0056
TV	Toshiba	0154 0156 0060 1256
TV	Tosonic	0185

TV	Vector Research	0030
TV	Victor	0053
TV	Vidikron	0054
TV	Vidtech	0178 0019
TV	Wards	0054 0165 0030 0178 0021 0019 0179 0056 0016
TV	Waycon	0156
TV	White-Westinghouse	0463 0623
TV	Yamaha	0030 0019
TV	Zenith	0017 0463 0016 0092
TV DVD Combo	Konka	0179 0720
TV DVD Combo	Sharp	0630
TV VCR Combo	Broksonic	0002
TV VCR Combo	Citizen	0278
TV VCR Combo	Colt	0072
TV VCR Combo	Emerson	0002
TV VCR Combo	Funai	0000
TV VCR Combo	GE	0240
TV VCR Combo	Harley Davidson	0000
TV VCR Combo	Hitachi	0000
TV VCR Combo	Lloyd's	0000
TV VCR Combo	Magnasonic	0278
TV VCR Combo	Magnavox	0000
TV VCR Combo	Magnin	0240
TV VCR Combo	MGA	0240
TV VCR Combo	Memorex	0037 0454 1037 1162 1262
TV VCR Combo	Optimus	0454 1162 1262
TV VCR Combo	Orion	0002
TV VCR Combo	Penney	0240 1035 1237
TV VCR Combo	Quasar	1162
TV VCR Combo	Radio Shack	1037
TV VCR Combo	RCA	0240
TV VCR Combo	Sansui	0000
TV VCR Combo	Sanyo	0240
TV VCR Combo	Sears	0000
TV VCR Combo	Sony	0000
TV VCR Combo	Symphonic	0000
TV VCR Combo	Thomas	0000
TV VCR Combo	Zenith	0000
VCR	Admiral	0048 0209
VCR	Adventura	0000
VCR	Aiko	0278
VCR	Aiwa	0037 0000 0307
VCR	Akai	0041 0106
VCR	America Action	0278
VCR	American High	0035
VCR	Asha	0240

VCR	Audiovox	0037 0278
VCR	Beaumarck	0240
VCR	Bell & Howell	0104
VCR	Broksonic	0184 0121 0209 0002 0479
VCR	CCE	0072 0278
VCR	Calix	0037
VCR	Canon	0035
VCR	Capehart	0020
VCR	Carver	0081
VCR	Cineral	0278
VCR	Citizen	0037 0278
VCR	Colt	0072
VCR	Craig	0037 0047 0240 0072 0271
VCR	Curtis Mathes	0060 0035 0162 0041 0760
VCR	Cybernex	0240
VCR	Daewoo	0045 0278 0020
VCR	Daytron	0020
VCR	Denon	0042
VCR	Dynatech	0000
VCR	Electrohome	0037
VCR	Electroponic	0037
VCR	Emerex	0032
VCR	Emerson	0037 0184 0000 0121 0043 0209 0002 0278 0208 0479
VCR	Fisher	0047 0104
VCR	Fuji	0035 0033
VCR	Funai	0000
VCR	GE	0060 0035 0240 0760
VCR	Garrard	0000
VCR	Go Video	0279 0432 0526
VCR	GoldStar	0037 0038
VCR	Gradiente	0000
VCR	HI-Q	0047
VCR	Harley Davidson	0000
VCR	Harman/Kardon	0081 0038
VCR	Harwood	0072
VCR	Headquarter	0046
VCR	Hitachi	0000 0042 0041
VCR	Hughes Network Systems	0042
VCR	JVC	0067 0041
VCR	Jensen	0041
VCR	KEC	0037 0278
VCR	KLH	0072
VCR	Kenwood	0067 0041 0038
VCR	Kodak	0035 0037
VCR	LXI	0037
VCR	Lloyd's	0000 0208

VCR	Logik	0072
VCR	MEI	0035
VCR	MGA	0240 0043
VCR	MGN Technology	0240
VCR	MTC	0240 0000
VCR	Magnavox	0035 0039 0081 0000 0149
VCR	Magnin	0240
VCR	Marantz	0035 0081
VCR	Marta	0037
VCR	Matsushita	0035 0162 0454
VCR	Memorex	0035 0162 0037 0048 0039 0047 0240 0000 0104 0209 0046 0307 0454 0479 1037 1162 1262
VCR	Minolta	0042
VCR	Mitsubishi	0067 0043
VCR	Motorola	0035 0048
VCR	Multitech	0000 0072
VCR	NEC	0104 0067 0041 0038
VCR	Nikko	0037
VCR	Noblex	0240
VCR	Olympus	0035
VCR	Optimus	1062 0162 0037 0048 0104 0432 0454 1048 1162 1262
VCR	Orion	0184 0209 0002 0479
VCR	Panasonic	1062 0035 0162 0225 0454 0616 1162 1262
VCR	Penney	0035 0037 0240 0042 0038
VCR	Pentax	0042
VCR	Philco	0035 0209 0479
VCR	Philips	0035 0081 0618 1081 1181
VCR	Pilot	0037
VCR	Pioneer	0067
VCR	Polk Audio	0081
VCR	Portland	0020
VCR	Profitronic	0240
VCR	Proscan	0060 0760
VCR	Protec	0072
VCR	Pulsar	0039
VCR	Quarter	0046
VCR	Quartz	0046
VCR	Quasar	0035 0162 0454 1162
VCR	RCA	0060 0240 0042 0149 0106 0760
VCR	RadioShack	0000 1037
VCR	Radix	0037
VCR	Randex	0037
VCR	Realistic	0035 0037 0048 0047 0000 0104 0046
VCR	ReplayTV	0614 0616

VCR	Runco	0039
VCR	STS	0042
VCR	Samsung	0240 0045
VCR	Sanky	0048 0039
VCR	Sansui	0000 0067 0209 0041 0271 0479
VCR	Sanyo	0047 0240 0104 0046
VCR	Scott	0184 0045 0121 0043
VCR	Sears	0035 0037 0047 0000 0042 0104 0046
VCR	Semp	0045
VCR	Sharp	0048
VCR	Shintom	0072
VCR	Shogun	0240
VCR	Singer	0072
VCR	Sonic Blue	0614 0616
VCR	Sony	0035 0032 0000 0033 0636 1032
VCR	Sylvania	0035 0081 0000 0043
VCR	Symphonic	0000
VCR	TMK	0240 0208
VCR	Tatung	0041
VCR	Teac	0000 0041
VCR	Technics	0035 0162
VCR	Teknika	0035 0037 0000
VCR	Thomas	0000
VCR	Tivo	0618 0636
VCR	Toshiba	0045 0043
VCR	Totevision	0037 0240
VCR	Unitech	0240
VCR	Vector	0045
VCR	Vector Research	0038
VCR	Video Concepts	0045
VCR	Videomagic	0037
VCR	Videosonic	0240
VCR	Villain	0000
VCR	Wards	0060 0035 0048 0047 0081 0240 0000 0042 0072 0149 0760
VCR	White Westinghouse	0209 0072
VCR	XR-1000	0035 0000 0072
VCR	Yamaha	0038
VCR	Zenith	0039 0000 0209 0033 0479